



Line Marking Floor Paint


SURFACE PREPARATION

- 
- Surfaces to be repaired must be clean, dry and free of any loose, friable material.
 - A wire brush is effective for removing surface contamination followed by sweeping out the repair area.
 - For larger areas, recommend hiring floor preparation equipment such as an upright floor grinder. A large industrial vacuum from the same hire shop can be used to remove all surface dust and debris. Please call our help line for further information.
 - RizistalClean can be used as a degreaser if there are small areas of oil or grease contamination.

MIXING

- 
- Each Floor Paint pack is housed within a large tin that in turn houses the resin tin and a separate tin of hardener.
 - Empty the two resin and hardener components into the larger tin making sure you scrape as much of the contents of each component out of each tin.
 - Mix thoroughly using a mixing paddle attached to a drill until you achieve a uniform colour and consistency.
 - We recommend wearing safety glasses, gloves, a mask and coveralls for this operation (available separately).

APPLICATION

- 
- Mark out your area and lines using durable floor tape.
 - If a narrow, short pile roller is to be used to apply the coating (recommended), the mixed contents can be emptied into a paint scuttle to allow roller access.
 - Apply the Floor Paint to the prepared surfaces with a roller or brush.
 - Work the material into the surface with even, parallel strokes.
 - For the best finish, re-work the previous 2-3 square metres periodically with light, parallel, one-way strokes.

For further information please contact the Support Team



Line Marking Floor Paint

4

WORKING TIME

The following approximate working times are for installing the product after mixing is complete but before the curing process affects your ability to move the material and smooth the surface. At this point the performance of the material will be adversely affected and should be discarded.

- Epoxy Line Marking Paint: 30 – 40 mins @ 15°C
- Polyaspartic Line Marking Paint: 15 - 25 mins @ 15°C

5

CURING TIME

	All Traffic	Full Chemical Cure
Polyaspartic	15 Hours	5 - 7 Days
Epoxy	2 - 8 Hours	5 - 7 Days

After installation, this product must be kept clean and dry for 12 to 18 hours, otherwise the product performance will be seriously affected, which may result in discolouration and lack of cure.

For further information please contact the Support Team

